








DAIKIN

INSTALLATION MANUAL

Remote controller

BRC315D7





READ THIS MANUAL ATTENTIVELY BEFORE STARTING UP THE UNIT. DO NOT THROW IT AWAY. KEEP IT IN YOUR FILES FOR FUTURE REFERENCE.



IMPROPER INSTALLATION OR ATTACHMENT OF EQUIPMENT OR ACCESSORIES COULD RESULT IN ELECTRIC SHOCK, SHORT-CIRCUIT, LEAKS, FIRE OR OTHER DAMAGE TO THE EQUIPMENT. BE SURE ONLY TO USE ACCESSORIES MADE BY DAIKIN WHICH ARE SPECIFICALLY DESIGNED FOR THE USE WITH THE EQUIPMENT AND HAVE THEM INSTALLED BY A PROFESSIONAL.


IF UNSURE OF INSTALLATION PROCEDURES OR USE, ALWAYS CONTACT YOUR DEALER FOR ADVICE AND INFORMATION.

The English text is the original instruction. Other languages are translations of the original instructions.

The equipment is not intended for use in a potentially explosive atmosphere.

The kit includes the following parts:

Remote controller	Wood screws



1. Remove the upper part of remote controller [\(Refer to figure 1\)](#)

Insert a minus screwdriver into the slots (1) in the lower part of the remote controller (2 places), and remove the upper part of the remote controller.



The PC board is mounted in the upper part of the remote controller. Be careful not to damage the board with the minus screwdriver.

2. Fasten the remote controller [\(Refer to figure 2\)](#)

- for exposed mounting, fasten with the 2 included wood screws (Ø4x30) and plugs.
- for flush-mounting, fasten with the 2 included machine screws (M4x16).

For the field supplied switch box, use optional accessory KJB11A or KJB21A.

NOTE Choose the flattest place possible for the mounting surface. Be careful not to distort the shape of the lower part of the remote controller by overtightening the mounting screws.



3. Wire the indoor unit (Refer to figure 6)

- 1 indoor unit
- 2 lower part of the remote controller
- 3 upper part of the remote controller
- 4 wired from the rear
- 5 wired from the top
- 6 notch the part for the wiring to pass through with nippers, etc.

Connect the terminals on top of the upper part of the remote controller (P1, P2), and the terminals of the indoor unit (P1, P2). (P1 and P2 do not have polarity.)

NOTE When wiring, run the wiring away from the power supply wiring in order to avoid receiving electric noise (external noise).

Wiring specifications

Wiring type	Size
2 wire	0.75–1.25 mm ²

NOTE Peel the shield for the part that has to pass through the inside of the remote controller case (✓). Refer to [figure 5](#).



4. Reattach the upper part of the remote controller

Be careful not to pinch the wiring when attaching.

Refer to [figure 4](#).

First begin fitting from the clips at the bottom.

- NOTE**
1. The switch box and wiring for connection are not included.
 2. Do not directly touch the PC board with your hand.

If controlling 1 indoor unit or 1 group of indoor units with 2 remote controllers

Change the MAIN/SUB changeover switch setting as described below ([Refer to figure 3](#)).

- 1 Main remote controller (factory set)
- 2 Sub remote controller

Set 1 remote controller to "main", and the other to "sub".

- NOTE**
1. If controlling with 1 remote controller, be sure to set it to "main".
 2. Set the remote controller before turning the power supply on.

"88" is displayed for about 1 minute when the power supply is turned on. During this time the remote controller can not be operated.

5. Field settings

If optional accessories are mounted on the indoor unit, the indoor unit setting may have to be changed. Refer to the instruction manual for each optional accessory.

Refer to figure 7.

- a Unit NO
- b First Code NO
- c Second Code NO
- d Mode NO
- e Field set mode

Procedure (Refer to figure 7)

- 1 When in the normal mode, press the "" button for a minimum of 4 seconds, and the FIELD SET MODE is entered.
- 2 Select the desired MODE NO. with the "" button.
- 3 During group control, when setting by each indoor unit (mode No. 20, 22 and 23 have been selected), push the "" button and select the INDOOR UNIT NO. to be set. (This operation is unnecessary when setting by group.)
- 4 Push the "" upper button and select FIRST CODE NO.
- 5 Push the "" lower button and select the SECOND CODE NO.
- 6 Push the "" button once and the present settings are SET.
- 7 Push the "" button to return to the NORMAL MODE.

Example

If during group setting and the time to clean the air filter is set to FILTER CONTAMINATION - HEAVY, SET MODE NO. to "10", FIRST CODE NO. to "0", and SECOND CODE NO. to "02".



- NOTE**
1. Setting is carried out in the group mode, however, if the mode number inside the parentheses is selected, indoor units can also be set individually.
 2. The SECOND CODE number is set to "01" when shipped from the factory.
 3. Do not make any settings not given in the table.
 4. Not displayed if the indoor unit is not equipped with that function.
 5. When returning to the normal mode, "88" may be displayed in the LCD in order for the remote controller to initialize itself.
 6. It is not possible to change field settings on the remote controller that is set to "sub".
 7. Changing of operation mode may not be available for some models.
 8. Do not set the filter type as standard filter on FWF+FWC types.

6. Enabling the operation change button (Refer to figure 3)

Cut off the jumper wire (J8) at the top right corner of the remote controller PCB to enable the customer to change the operation mode with the operation change button "▲▼".

NOTE If a centralised remote controller is used, it is better to cut jumper "J8" to have control with the wired remote controller.

7. Enabling auto mode heating/cooling display (Refer to figure 3)

Normally, if auto mode is selected, " AUTO " icon will be shown on the remote controller, but it will not be shown when the unit is in heating or cooling mode.

If jumper "J5" is cut, the heating or cooling icon will also be shown while the unit is in auto mode.

NOTES



Mode No. ^(*)	FIRST CODE NO.	Description of setting	SECOND CODE NO. ^(†)				Factory setting	
			01	02	03	FWF + FWC		
10(20)	0	Filter Contamination - Heavy/ Light (Setting for spacing time of display time to clean air filter) (Setting for when filter contamination is heavy, and spacing time of display time to clean air filter is to be halved)	Long life filter Standard filter	Approx. 2500 hrs. Approx. 200 hrs.	Approx. 1250 hrs. Approx. 100 hrs.	— —	Light	
		Long-life filter type (setting of filter sign indication time)	Long-life filter	—	Standard filter ^(‡)	Long-life filter	Standard filter	
	2	Thermostat sensor in remote controller	Use	Not used	—	Not used		
	3	Spacing time of display time to clean air filter count (setting for when the filter sign is not to be displayed)	Display	Do not display	—	Display	Do not display	
12(22)	2	Airflow over thermistor during thermo off	L (LL)	OFF	Remote controller selected fan speed	L (LL)	L	
	8	ON/OFF input from outside (setting for when forced ON/OFF is to be operated from outside)	Forced OFF	ON/OFF operation	Protective equipment input	Forced OFF		
13(23)	0	High air outlet velocity (for high ceiling applications)	≤2.7 m	>2.7≤3.0 m	>3.0≤3.5 m	≤2.7 m	—	
	1	Selection of air flow direction (setting for when a blocking pad kit has been installed)	4-way flow	3-way flow	2-way flow	4-way flow	—	
	4	Air flow direction range setting	Upper	Normal	Lower	Normal	—	

(*) Setting is carried out in the group mode, however, if the mode number inside the parentheses is selected, indoor units can also be set individually.

(†) The SECOND CODE number is set to "01" when shipped from the factory.

(‡) Can not be selected on FWF and FWC units.



4PW64948-1 00000001

Copyright 2010 Daikin

DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium

4PW64948-1 10.2010